Contents

- Query user for logfile
- Separate raw, bandpassed, and motion filtered data from scn structure
- Pull out the raw scans (if saved)
- Create the waterfall horizontal and vertical axes
- 6
- 7
- 8
- 9

```
% plotMrmRetLog.m
% This script prompts the user for a MRM-RET logfile, reads, parses, and
% produces a "waterfall plot" of the motion filtered scans and detection lists
% in the logfile
clear all; close all; clc %#ok<*CLALL>
```

Query user for logfile

```
%dnm = '.'; fnm = 'MRM_002.csv';
[fnmb,dnmb] = uigetfile('*.csv');
fprintf('Reading logfile %s\n',fullfile(dnmb,fnmb));
[cfgb,reqb,scnb,det] = readMrmRetLog(fullfile(dnmb,fnmb));
[fnmt,dnmt] = uigetfile('*.csv');
fprintf('Reading logfile %s\n',fullfile(dnmt,fnmt));
[cfgt,reqt,scnt,dett] = readMrmRetLog(fullfile(dnmt,fnmt));
Reading logfile C:\Users\austinsbrown\Dropbox\ee384\lab11\background.csv
Reading logfile C:\Users\austinsbrown\Dropbox\ee384\lab11\scan.csv
```

Separate raw, bandpassed, and motion filtered data from scn structure

(only motion filtered is used)

Pull out the raw scans (if saved)

```
rawscansI = find([scnb.Nfilt] == 1);
rawscansV_background = reshape([scnb(rawscansI).scn],[],length(rawscansI))';
rawscansI1 = find([scnt.Nfilt] == 1);
rawscansV_target = reshape([scnt(rawscansI1).scn],[],length(rawscansI1))';
scan_difference = abs(rawscansV_background(1:10,:) - rawscansV_target(1:10,:));
```


Create the waterfall horizontal and vertical axes


```
Tbin = 32/(512*1.024); % ns
T0 = 0; % ns
c = 0.29979; % m/ns
Rbin = c*(Tbin*(0:size(scan_difference(1,:),2)-1) - T0)/2;% Range Bins in meters
rbin = 90;
```

```
%Background plot
% plot(rbin, rawscansV_background(10,:))
%Taget plot
figure; plot(Rbin, rawscansV_target(10,:)), title('Target')
% Difference plot
figure; plot(Rbin, scan_difference(10,:)), title('Difference')

[a,i]=max(scan_difference(10,:)); %#ok<ASGLU>
distance=Rbin(i) %#ok<NOPTS>

distance =
    0.9881
```







6

```
fs = 1/(Tbin*10^-9);


figure
l = length(scan_difference(10,:));
n = pow2(nextpow2(l));
y_dft = fft(scan_difference(10,:), n);
f = (-n/2:n/2-1)*(fs/n);
plot(f, abs(y_dft)/n);
title('6c ii'), xlabel('Frequncy'), ylabel('Magnitude')


figure
spectrum_plot(scan_difference(10,:), fs)
title('6c iii'), xlabel('Frequncy'), ylabel('Magnitude')
```





```
7
Wp = (2*(4.9*10^9))/fs;
Ws = (2*(5.6*10^9))/fs;
Rp = 1;
Rs = 20;
[Ord, Wn] = buttord(Wp, Ws, Rp, Rs);
[b,a] = butter(Ord, Wn, 'low');
yf = filter(b, a, scan_difference(10,:));
figure
spectrum_plot(yf, fs)
title('7b'), xlabel('Frequncy'), ylabel('Magnitude')
figure
plot(Rbin, yf)
title('7c')
```






```
Wp = (2*(.1*10^9))/fs;
Ws = (2*(.05*10^9))/fs;
Rp = 1;
Rs = 20;


[Ord, Wn] = buttord(Wp, Ws, Rp, Rs);
[b,a] = butter(Ord, Wn, 'high');
yf = filter(b, a, scan_difference(10,:));

figure
spectrum_plot(yf, fs)
```

8


```
title('8 Spectrum'), xlabel('Frequncy'), ylabel('Magnitude')
figure
plot(Rbin, yf)
title('8 Time Domain')
```








```
9
Wp = (2*(4.9*10^9))/fs;
Rp = 1;
Rs = 20;
[n1,Wn] = ellipord(Wp,Ws,Rp,Rs);
```

```
[b,a] = ellip(n1,Rp,Rs,Wp,'low');
yf = filter(b, a, scan_difference(10,:));
figure
spectrum_plot(yf, fs)
title('9 Lowpass '), xlabel('Frequncy'), ylabel('Magnitude')
figure
plot(Rbin, yf)
title('9 Lowpass'), xlabel('Distance')
Wp = (2*(4.9*10^9))/fs;
Rp = 1;
Rs = 20;
[n2,Wn] = ellipord(Wp,Ws,Rp,Rs);
[b,a] = ellip(n2,Rp,Rs,Wp,'low');
yf = filter(b, a, scan_difference(10,:));
figure
spectrum_plot(yf, fs)
title('9 highpass'), xlabel('Frequncy'), ylabel('Magnitude')
figure
plot(Rbin, yf)
title('9 highpass'), xlabel('Distance')
```









Published with MATLAB® R2020a

Questions

- **1.** It is inaccurate because we are using the abs function on the complex numbers. This causes some inaccurate measurements along the x axis.
- **2.** It centers the spectrum along the x axis.
- **3.** It gets rid of the peak at zero as well as smoothing out the other peaks.
- **4.** It also smooths out the top peaks. It also made the amplitude less than 0.
- **5.** I used 10 for the low pass Butterworth filter, 5 for the high pass. I used 3 for both elliptic filters. The elliptic filter performed better.